




# CABIN AIR FILTERS

Cabin filters are designed to keep dirt, dust, mold, mildew, pollen and other debris (leaves, insects, etc.) from entering the passenger compartment through the heating, A/C and defrosting systems.



Designed to retain virtually all pollen and unwanted particles.

Empowered with activated charcoal and anti-bacterial coated material to eliminate odors and harmful gases resulting from mold build-up.

Cabin filters should be checked annually to insure your filter is clean & free of debris.



# CABIN AIR FILTERS

- Designed to keep a vehicle's passenger compartment free from pollen, mold spores, bacteria, and other airborne contaminants.
- Eliminates odors if containing quality activated charcoal
- A clean cabin filter, allows smooth flow of air and operation of the vehicle's HVAC system
- Requires scheduled maintenance every 12k to 15k miles or at least once per year (additional services required based on road conditions)
- Automotive, LD, HD & Off-Road Equipment

## **PARTICULATE MEDIA FILTERS:**

- Particulate Matter - Particle pollution includes "inhalable coarse particles," smaller than 10 microns and "fine particles" < 2.5 microns
- Mold – a microscopic fungus that lives on plant and animal matter.

## **ACTIVATED CHARCOAL MEDIA FILTERS:**

- Mold – a microscopic fungus that lives on plant and animal matter.
- Odors elimination related
- Carbon Dioxide - CO<sub>2</sub>
- Nitrogen Oxides - (NO<sub>2</sub>)
- Sulfur Dioxide - (SO<sub>2</sub>) Ozone - (O<sub>3</sub>)

